



Maximum Water Level
Valve 0% OPEN

Minimum water Level
Valve 100% OPEN

Level Transmitter
(Power by others)

Span

Singer OMNI Control Panel
(SCADA or local controls)

Distribution to users

Singer model 106/206-2SC-PCO
c/w X136 Valve Position Transmitter
(24VDC Loop Powered upon request)