

Deep Well
Vertical Turbine Pump

Non-Slam Check Valve

Isolation Valve

Sensing line is connected to pipeline
downstream of the header check valve.

**Singer model 106-DW
or model 206-DW
Deep Well Pump Control Valve**
discharges back to sump or to
waste (atmosphere)

Provision should be made to
drain the small volume of water
released with each operation.

